



## **Tone Vise® Keyless Nut Locks Installation Instructions**

1. Using a 3mm hex wrench remove the stock cap screws and string clamping blocks from the nut base.
2. With a 2mm hex wrench remove the flat head cap screws from the top of the tightening posts. Remove the tightening post from the lock leaving the conical spring inside.
3. Place the larger end of a spring into the recess of a new clamping block. (Note: all 6 springs are identical).
4. Insert the threaded end of a tightening post through the top of the clamping block and spring assembly and thread it into the nut base. Install with the peak of the clamping block aligned parallel to the strings.
5. Place the keyless locks on to the tightening posts with the spring's larger end inserted first. Ensure there is grease in the 12 point socket.
6. Thread the small flat head cap screws back into the tightening posts. Tighten the lock by hand being careful to not over tighten. It doesn't require brute force to lock the strings.
7. For easiest access adjust the locks with a slightly splayed pattern.

*Enjoy the freedom of never being "locked out" of your guitar ever again!*



[www.tonevise.com](http://www.tonevise.com)

Pat. 9,542,915, Patents Pending.